SOUND SYSTEM HALL2

in OPERATING IT





The switch is located on the wall behind the sound system. Turn it ON to power up the sound system.



STEP Unlock and remove the covers of the Sound System



Unlock the four locks indicated and remove the covers to access the sound system.



STEP 2





Unlock the four locks indicated and remove the covers to access the sound system.



STEP Locate the two switches on the Sound System and turn ON



Switch 1 is at the base of the sound system. **Switch 2** is at the back of the mixer/amplifier.



STEP Adjust the levels on the Mixer to the level indicated.



The pictures above shows the ideal levels the mixers are to be set. Refer to the pictures above for guidance.



STEP 5 Locate and Ensure that the microphone(s) cords are Plugged-in






Ensure that the right microphone cords are plugged in the right sockets.



STEP Switch ON and test the microphone and/or other equipment.



Test the microphone by checking if sound is coming out from the TWO speakers. Also, ensure that there is no audio feedback (buzzing/hissing sound).